
bCUBE® 2.0 Quick Start Guide

Document Revision: 1.2.3

Hyris Ltd

HYRIS Headquarters

41 Chalton St.,
London, UK, NW1 1JD
Phone: +44.2036082968
Mail: office@hyris.net

HYRIS Research Center

C.so Garibaldi 60,
Milano 10121, Italy
Phone: +39.02.82951302
Mail: administrator@hyris.net

HYRIS Asia Pac

Block 998 Toa Payoh North #06-06
Toa Payoh North Industrial Estate
Singapore 318993, Singapore
Phone: +65.8160.7207
Mail: office@hyris.net

www.hyris.net



Copyright ©2018 Hyris Ltd. All rights reserved.

Reproduction of this document, either in printed or electronics form, is prohibited without the permission of Hyris Ltd.

Information in this document is subject to change without notice. Hyris Ltd assumes no responsibility for any incorrect information that may appear in this document.

Please, refer to the Owner's manual for complete safety and functional information.

Notice:

bCUBE® 2.0 is only for research purpose and for all other fields except for in vitro diagnostics.

HYRIS LTD DISCLAIMS ALL WARRANTIES WITH RESPECT TO THIS DOCUMENT, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL HYRIS LTD BE LIABLE, WHETHER IN CONTRACT, TORT, WARRANTY, OR UNDER ANY STATUTE OR ON ANY OTHER BASIS FOR SPECIAL, INCIDENTAL, INDIRECT, PUNITIVE, MULTIPLE OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THIS DOCUMENT, INCLUDING BUT NOT LIMITED TO THE USE THEREOF.

Trademarks:

bCUBE® and bDATA® are registered trademarks of Hyris Ltd.

Microsoft® and Windows® are registered trademarks of Microsoft Corporation. FAM™ is a trademark of Applera Corporation or its subsidiaries in the U.S. and certain other countries. VIC® is a registered trademark of Applera Corporation or its subsidiaries in the U.S. and certain other countries.

Technical Support Contacts:

Hyris Ltd – Italian Branch

Corso Garibaldi 60, 20121 Milano (MI) – ITALY

Phone: +39 02 82951302

Website: <http://hyris.net>

Summary

Figure Index	4
Hyris bcUBE® 2.0	6
Box Opening	6
Device Overview	7
Status LEDs	8
First set up	10
PC settings	10
bcUBE® 2.0 Connection.....	11
Interacting bcUBE® 2.0: bAPP and bPANEL.....	12
bAPP interface	13
Access the bAPP	13
Create a New Analysis.....	14
Run the analysis.....	17
bPANEL 2.0 interface	18
Installation.....	18
Main view	19
Settings: Log in/Sync and bcUBE® 2.0 connection.....	20
New analysis creation.....	22
Run the analysis.....	23
Old analyses view	23
Flow Chart.....	25
Appendix-1: Set bcUBE® 2.0 Wi-Fi	26
Appendix-2: Custom Recipe.....	26
Appendix-3: Cartridge Preparation.....	27
Load samples	27
Load cartridge to bcUBE® 2.0.....	27

Figure Index

Figure 1: Box content. (a) bcUBE® 2.0. (b) Ethernet cable. (c) DC power supply. (D) USB stick	6
Figure 2: bcUBE® 2.0 isometric view	7
Figure 3: bcUBE® 2.0 back view	7
Figure 4: bcUBE® 2.0 front view - Cartridge slot detail	8
Figure 5: bcUBE® 2.0 status LEDs	9
Figure 6: Windows Control Panel - Network and Sharing Center view	10
Figure 7: Windows Control Panel - Wi-Fi Properties settings view	11
Figure 8: bcUBE® 2.0 connection - Suggested conFiguretion	12
Figure 9: Google Chrome address bar	13
Figure 10: bAPP interface - Main View example	14
Figure 11: General Information view – Analysis Creation - bAPP	15
Figure 12: Sample View - Analysis creation - bAPP	15
Figure 13: Sample Well Selection - bAPP	16
Figure 14: Well Information Editing - bAPP	16
Figure 15: Analyses list -bAPP	17
Figure 16: Analysis Tools Menu -bAPP	17
Figure 17: Analysis Overview - bAPP	18
Figure 18: bPANEL installation - Welcome screen.....	19
Figure 19: bPANEL installation - License Agreement view	19
Figure 20: bPANEL Overview	20
Figure 21: Settings Tab - bPANEL.....	20
Figure 22: Log In Window - bPANEL	21
Figure 23: Settings View with completed information - bPANEL	21
Figure 24: New Analysis window	22
Figure 25: Sample Tab View - bPANEL.....	22
Figure 26: Needed Sample Information - bPANEL.....	23
Figure 27: Load Analysis View - bPANEL.....	24

Figure 28: Process Overview - Flow Chart	25
Figure 29: Wi-Fi Setup Window - bAPP	26
Figure 30: Available Recipe List - bAPP	26
Figure 31: Cartridge Side View	27

Hyris bCUBE® 2.0

Box Opening

The following items will be found in the provided box:

- **bCUBE® 2.0** (Figure 1a)
- **Ethernet cable** (Figure 1b)
- **Power Supply** including European and North American power cords (Figure 1c).

Characteristics:

- **Input:** 100 ~ 240 V c.a. 1.4A 50/60Hz
 - **Output:** 12V DC 5A
 - **Power:** 60W
- **USB stick** with Hyris bPANEL software installer and User Manuals (Figure 1d)



Figure 1: Box content. (1.a) bCUBE® 2.0. (1.b) Ethernet cable. (1.c) DC power supply. (1.d) USB stick

NOTE: Please check the presence of all these items. Remove the items carefully from the shipping box and inspect them for any external damage. If any of the parts is missing or damaged, contact the manufacturer prior to installation.

Device Overview




Figure 2: bCUBE® 2.0 isometric view




Figure 3: bCUBE® 2.0 back view








Figure 4: bCUBE® 2.0 front view - Cartridge slot detail



Description of the features highlighted in the pictures above:

- **Access Port Slider:** opened to insert/remove the cartridge inside bCUBE® 2.0. To be kept closed during operations.
- **Access Port:** cartridge slot. Always push the cartridge up to the end of the port.
- **Power supply Plug:** insert here the 12 VDC adapter jack
- **Power-on/Power-off button:** press shortly to wake up the instrument from Stand-By. When the machine is running, long press (about 5 seconds) to safely power down the bCUBE
- **Ethernet Plug:** insert here the Ethernet cable for Windows PC / Network communication
- **Status LEDs:** Give information about the status of the instrument

Status LEDs

The status of the bCUBE and its functioning are communicated to the user by the different color combinations of the status LEDs on the top of the device.

- **bDATA LED:** corresponding to the  symbol, it indicates the connection status to Hyris server.
Ready color: green 
When Ready color is on, bCUBE® 2.0 is connected to bDATA
- **Thermal LED:** corresponding to the  symbol, it indicates if the cartridge is hot or not.
Ready color: orange 
When Ready color is on, the internal temperature of the bCUBE® 2.0 is not hot. If cartridge is inserted, it can be safely handled

- **Connection LED:** corresponding to the  symbol, it indicates the internet connection state of the bCUBE® 2.0
Ready color: blue 
When ready color is on, bCUBE® 2.0 is connected to the internet









Figure 5: bCUBE® 2.0 status LEDs

For a graphical representation, the  symbol (from left to right: bDATA, Thermal and Connection LEDs) will be displayed in this document when color code explanation is required.

Some examples are reported in the following table:

LEDs COLORS	DESCRIPTION	INTERPRETATION
	<ul style="list-style-type: none"> - bDATA LED steady green - Thermal LED steady orange: - Connection LED steady blue: 	<ul style="list-style-type: none"> - bDATA connection OK - Cartridge not hot - Internet connection OK
	<ul style="list-style-type: none"> - bDATA LED steady green - Thermal LED blinking orange and red - Connection LED steady blue 	<ul style="list-style-type: none"> - bDATA connection OK - WARNING: Cartridge hot - Internet connection OK
	<ul style="list-style-type: none"> - bDATA LED multicolor - Thermal LED multicolor - Connection LED multicolor 	<ul style="list-style-type: none"> - Experiment is running on bCUBE® 2.0
	<ul style="list-style-type: none"> - bDATA LED off - Thermal LED off - Connection LED off 	<ul style="list-style-type: none"> - bCUBE® 2.0 off

NOTE: not all the Status LEDs color combinations are shown. For further information, please read the Owner's Manual

First set up

PC settings

Some preliminary steps are necessary in order to properly connect the bCUBE® 2.0:

1. Make your PC/Laptop has nothing connected to the Ethernet port (**bCUBE® 2.0 off and not connected**)
2. Open “Network and Sharing Center”
3. Click on “Change adapter settings” (see image below)




Figure 6: Windows Control Panel - Network and Sharing Center view

4. Right-click on your Wi-Fi connection icon, click on “Properties”, go to “Sharing” tab and check the box “Allow other network users to connect through this computer’s internet connection”. Choose “Ethernet” from the list of networking connections (this list may not be available on all Windows versions, in that case ignore this).




Figure 7: Windows Control Panel - Wi-Fi Properties settings view

5. Now you can connect your bCUBE® 2.0 to your laptop. **Make sure that bCUBE® 2.0 is turned on after the ethernet cable is correctly wired to your PC/Laptop, otherwise a successful connection may not be possible.**

bCUBE® 2.0 Connection

In order to properly work, the following steps have to be respected:

1. Make sure the bCUBE® 2.0 is set on a flat and stable surface
2. Make sure to have correctly followed the steps in the [PC Set-up](#) section

3. Connect one end of the Ethernet cable to the bCUBE® 2.0 and the other to the PC according the following configuration








Figure 8: bCUBE® 2.0 connection - Suggested configuration

4. **Power** on the PC. Wait until PC is ready
 5. **Connect** the PC to internet. Make sure internet connection is stable
 6. Power on the bCUBE® 2.0. Status LEDs colors: 
 7. bCUBE will start booting. Status LEDs colors: 
 8. Wait about a minute for Status LEDs Ready colors: 
- If LEDs colors are different from the LEDs Ready colors, try to repeat the steps. Otherwise, check the Owner's Manual

NOTE: Status LEDs may display different colors while bCUBE® 2.0 is looking for internet connection from point nr7 to point nr8. If no connection is available, the following LEDs colors may be displayed even after a minute of waiting time: . Repeat the [PC Set-up](#) steps. If the problem persists, see the Owner's Manual.

Interacting bCUBE® 2.0: bAPP and bPANEL

bCUBE® 2.0 can be controlled and monitored with two Hyris tools: bAPP and bPANEL.

- **bAPP:** it's a web app software and there's no need to install it on the PC. Ready-to-use recipes or custom recipes (see dedicated section) can be used to create and run analyses on the available devices according to


the account permissions. Account and devices management are possible by this application. It can run on PC or Smartphone. **Internet connection is mandatory.**

- **bPANEL:** this software interface is designed for **offline** usage of the bCUBE device, while also providing internet data sharing when connection is available. bPANEL 2.0 can start new analyses by using the already existing recipes (created on bAPP).

bAPP interface

Access the bAPP

1. Make sure to have properly followed the instruction described in the [bCUBE 2.0® Connection](#) section.

If bCUBE® 2.0 is ready for operations, open the internet browser (Google Chrome  browser recommended) on the PC and type <https://bapp.hyris.net> in the address bar. Then press enter to access the bAPP.




Figure 9: Google Chrome address bar

2. The **Home** window will be shown. The screen is mainly divided in two sections:
 - **Main Menu:** list of available bAPP sections:
 - **Home:** Welcome Window. Log-in credentials required when starting a new session on bAPP
 - **Swarms:** “Swarm” is used to define a collector of analyses and recipes. User can have access to multiple swarms according to his permissions. Visible Swarms are listed in this sections
 - **Analyses:** all the available analyses are listed in this section. New analyses can be created
 - **Recipes:** a “Recipe” is a detailed list of steps and settings that the bCUBE has to execute while performing an analysis. New recipes can be customized from this menu (see [Appendix-2: Custom Recipe](#)). All the available recipes are listed here
 - **Users:** list of available users and relative permissions (see Owner’s Guide for further information)
 - **bCUBEs:** list of available bCUBEs with relative extra information (see Owner’s Guide for further information)
 - **Tab View Area:** content is related to the selected Main Menu section




Figure 10: bAPP interface - Main View example


3. After the Main Window is displayed, **Log-In** is required.

Insert your email and password, which are corresponding to the **credentials** used to register the user to the Hyris Ltd web site.

In case of forgotten password, press on “**FORGOT PASSWORD?**” and insert the user mail. Then check your mail box for further instructions.


Create a New Analysis

Click on the “**Analyses**” button on the left side main menu. The already existing analyses will be listed in a table.

Click on the  button to add a new analysis. Fill the spaces with the required information. Following steps are required:

1. Insert the **Analysis Name** (Mandatory)
2. Select the **Swarm** among the available swarm list (Mandatory). This result depends on the user permissions
3. Add a brief analysis description (Optional)
4. Select the desired **Recipe** among the available ones according to the selected swarm. If no recipes are available select “**Global Recipe**” to access the recipes provided by Hyris. (Mandatory)

5. Click on “**CONTINUE**” to proceed.




The screenshot shows the 'General Information' form in the bAPP. It has a sidebar with a blue circle containing the number '1'. The form fields are:

- Name:** This Is A Test
- Description:** Demo analysis
- Swarm:** Test
- Global Recipe:** test_edit
- Global Recipe toggle:** A blue toggle switch is turned on.

A blue **CONTINUE** button is at the bottom left.


Figure 11: General Information view – Analysis Creation - bAPP

6. The wells information are filled while compiling the selected recipe.



The screenshot shows the 'Cartridge' view in the bAPP. It has a sidebar with a blue circle containing the number '2'. The main area is a 3x3 grid of wells. The top-left well is highlighted with an orange border and contains a sample icon, a location pin icon, and a trash icon. The other wells are labeled 'Not selected'. To the right of the grid is a 3x3 grid of numbered circles (1-9). Circle 1 is orange, and the others are grey. Below the circles are two radio buttons: '3x3 samples' (selected) and '4x4 samples'. At the bottom left are blue **FINISH** and **BACK** buttons.

Figure 12: Sample View - Analysis creation - bAPP

7. Wells can be deleted (press the  linked to the desired well), modified or added. In this last case:
 - a) Click on the desired well on the cartridge model on the right, according to the loaded sample





Figura 13: Sample Well Selection - bAPP


- b) A dedicated window will appear
- c) Select the **Sample Type** from the drop-down menu (Mandatory)
- d) Enter the **Sample Name** (Mandatory)
- e) Choose the **Well Color**
- f) Click on “**SAVE**” button

Select type for well nr. 2

Select well type ▼

Title





CANCEL
SAVE

Figura 14: Well Information Editing - bAPP

- Click on **“FINISH”** button. The new analysis will be added to the analyses list (Click on “Date” to order the list by the creation date)

	↑ Date	↑ Name	↑ User	↑ Department	↑ Swarm	↑ Status
<input type="radio"/>	2018-01-22 10:43:52	This Is A Test	Davide	Hyris R&D	Test	Initialized

Figure 15: Analyses list -bAPP

Run the analysis

If an analysis status is **“Initialized”**, then it could be loaded to one of the available bCUBE® 2.0.







Figure 16: Analysis Tools Menu -bAPP

- Select the analysis by checking the ☐ symbol. A menu will appear to the top of the table.
- Check the cartridge is correctly loaded as shown in [Cartridge Preparation](#) section
- Press the  button and select the desired bCUBE® 2.0.
- Click on **“SEND”**. If no errors occurred, the analysis will automatically start, while the status LEDs of the device will start to show multiple and changing colors . Otherwise, check the Owner’s manual for further information

Analysis parameters are updated in real time while bCUBE® 2.0 is connected to internet. To follow the real time experiment results:

- Select the running analysis and click on the  symbol. Different sections are available:
 - Analysis Name:** the current selected analysis name
 - Tab Selection:** each tabs provides different information about the selected analysis. If the selected analysis is running, the tabs information are updated in real time
 - Tab View Area:** the content of the selected tab




Figure 17: Analysis Overview - bAPP

bPANEL 2.0 interface

Installation

Open the bPANEL 2.0 installer located in the provided USB.

- 1) Insert into an available USB port the Hyris® USB Stick containing bPANEL installer.
- 2) Launch the file **Setup.msi**, located inside **bPANEL** folder.
- 3) On the welcome screen, click on **Next**.




Figure 18: bPANEL installation - Welcome screen

- 4) On the next page, carefully read the licence agreement. Tick the check-box and click **Install** to continue.




Figure 19: bPANEL installation - License Agreement view

- 5) Wait for the installation process to end. Click on **Finish** on the last page to complete the installation.

No driver installation is required for using bcUBE® 2.0.

Main view

Make sure all the steps described in [bcUBE 2.0® Connection](#) have been correctly performed.

Open the bPANEL 2.0 program. The main view will be shown:

- **Command Buttons:** list of command to send to the connected bcUBE
- **Tab selection:** each tab provides different information about the loaded analysis or the user settings. The analysis related tab are updated in real time while the selected analysis is running and the correspondent bcUBE is connected

- **Tab View Area:** shows the content of the selected tab




Figure 20: bPANEL Overview

Settings: Log in/Sync and bCUBE® 2.0 connection

Go to “Settings” tab:

1. Click on “Login”





Figure 21: Settings Tab - bPANEL


2. Insert your **email** and **password**, which are corresponding to the **credentials** used to register the user to the Hyris Ltd web site (same as used credential to access the bAPP. See [Access the bAPP](#) section for further information). Then click “**OK**”



A login dialog box titled "Login" with a close button (X) in the top right corner. It contains two input fields: "bData Username:" with the text "TestUser@demo.net" and "bData Password:" with masked text "*****". Below the fields are two buttons: "Ok" and "Cancel".


Figure 22: Log In Window - bPANEL

3. Click on “**Clear/Refresh**”. After the operation completion, the available bCUBE devices will be listed in the dedicated drop-down menu. Select the desired one



The Settings view of the bPANEL interface. It has two tabs: "Protocol" and "Settings", with "Settings" being the active tab. Below the tabs, there is a section for "bCube IP/Name" with a dropdown menu showing "BIOX" and a "Clear/Refresh" button. Below this, there is a section for user information showing "bData Username: TestUser@demo.net" and "Last Sync: 23/01/2018 17:41:33". At the bottom of this section are three buttons: "Logout", "Login", and "Sync".

Figure 23: Settings View with completed information - bPANEL

4. Click on the  button to connect to the selected device. After connection, the button will turn green




1. Click on the  button
2. Insert the **Analysis Name** (Mandatory)
3. Select the desired **Swarm** among the available ones (Mandatory)
4. Select the desired **Recipe**
5. Click on “OK” button.

Figura 24: New Analysis window

Figura 25: Sample Tab View - bPANEL

7. Wells can be deleted, modified or added. In this last case:
 - a. Click on the desired well on the cartridge model on the right, according to the loaded sample
 - b. Select the **Sample Type** from the drop-down menu (Mandatory)
 - c. Enter the **Sample Name** (Mandatory)
 - d. Choose the **Sample Color**







Figure 26: Needed Sample Information - bPANEL

Run the analysis

1. Load the cartridge to the selected bCUBE® 2.0 (see section: [Cartridge Preparation](#)).
2. Run the analysis by clicking on the  command button. The analysis will be uploaded to the selected bCUBE® 2.0. If no errors occur, the experiment will immediately start, while the status LEDs of the device will start to show multiple and changing colors.
3. The analysis parameters and results will be automatically shown in specific tabs in real time.
4. Wait for “Ready Colors”
5. Generate a PDF report file by clicking on the  command button, and then selecting “**Build/Rebuild PDF Report**”.
6. Unload the cartridge

Old analyses view

Old analyses can be consulted by opening them from PC, bCUBE or online bDATA folders.

Click on the  command button and select the desired folder location among “**LOCAL**”, “**bCUBE**” and “**bDATA**”. Click on “**OK**” after the analysis selection. The analysis data will be loaded to bPANEL and results can be consulted. The opened analysis can’t be modified.




Figure 27: Load Analysis View - bPANEL

Flow Chart





Figure 28: Process Overview - Flow Chart

Appendix-1: Set bCUBE® 2.0 Wi-Fi

bCUBE® 2.0 can also be connected to internet via Wi-Fi. To do that, Wi-Fi has to be set up.

1. Follow the instructions described in the [bCUBE 2.0® Connection](#) section to properly connect the bCUBE® 2.0
2. Access the bAPP and Log In as shown in the [PC: bAPP Interface](#) section
3. Click on “**bCUBEs**” from the main menu: a list of the available devices will appear. The available devices could be different among users of the same company depending on their permissions.
4. Select the desired device and press the  button.
5. Select the desired LAN and set the Wi-Fi password, then click on “**SAVE**”.




Figure 29: Wi-Fi Setup Window - bAPP

6. Reboot the selected bCUBE.


Appendix-2: Custom Recipe

New recipes can be customized on the bAPP according to user’s permissions. If recipe customization is not allowed by user’s permissions, global recipes provided by Hyris Ltd or already existing company recipes can be used for new analyses.

1. Click on “**Recipes**” in the left side main menu: the list of the available recipes will be shown.

Recipes				
<div>+</div>				
Recipes				Columns ▾
🔍 Name	🔍 Description	🔍 Swarm	📅 Date	
<input type="radio"/>	ThisIsATest	Test Recipe	Test	10 01 2018 15:51:15

Figure 30: Available Recipe List - bAPP

2. Click on the  button to access to the new recipe customization form.
Remember that **Recipe name** and selected **Swarm** are mandatory.
3. Follow the steps and click on “**FINISH**” button.
4. The new recipe will added to the recipe list

Appendix-3: Cartridge Preparation

Load samples

In order to load the samples for the experiment:

1. Place the cartridge face up on a flat and stable surface
2. Put the sample in one or more of the cartridge wells as indicated in the reference Recipe.
3. Seal the cartridge with the provided aluminium foils



Figure 31: Cartridge Side View

Load cartridge to bCUBE® 2.0

To load the cartridge to the bCUBE® 2.0:

1. Open the bCUBE® 2.0 Access Port slider (see Owner’s Manual for more info)
2. Insert the cartridge by pushing it through the Access Port by keeping it face up holding it from the handle till it stops
3. Close the access port slider

To unload the cartridge:

1. Make sure the cartridge is not hot (see Owner’s Manual for further information)
2. Open the access port slider
3. Gently pull the cartridge from the handle
4. Close the access port slider